



LASERJET ENTERPRISE 700 COLOR MFP

Repair Manual



M775dn



M775f



M775z



M775

www.ServiceParts.nl

Fuser


1. Open the right door
2. Depress the two blue tabs on the fuser handles.

Figure 1-9 Remove the fuser (1 of 2)



3. Pull the fuser straight out of the product.

Figure 1-10 Remove the fuser (2 of 2)



www.ServiceParts.nl